

GENERAL PURPOSE CEMEN BASED TILE ADHESIVE

G



COVERAGE

3.5 to 4 kg/m² using a 6mm x 6mm notched trowel.

SHELF LIFE Up to 12 months in unopened original container.

STORAGE

Store in an elevated, cool dry place.

PACKAGING 25 kg bag.

DESCRIPTION

TILEBOND is a cement-based tile adhesive specially designed for internal and external floor and wall tiling. It is ideal for installing mosaics, ceramic and homogeneous tiles.

APPLICATION RANGE

- For the installation of absorptive and non-absorptive wall and floor tiles for interior and exterior surfaces.
- Suitable for tiling on concrete, rendered brickwork and blockwork.

TECHNICAL DATA

- : Grey/white powder Appearance Water/powder ratio : 0.22 - 0.24 (or 5.5 - 6.0 litres
 - of water per 25 kg bag) : Approx. 15 minutes
- Open time (23°C) Adjustability
 - : 15 20 minutes
- Recommended thickness : 3 6 mm depending on the size and type of tiles.

Pull off strength test: BS 1881 Part 207

28 days	>1 N/mm ²
Working time: ATM C 308	
60 minutes	
Tensile Adhesion - EN 1346;2007	
28 days @ 5 minutes	1.0 N/mm²

EN 12004: 2007 Test Analysis

Tensile Strength EN 1348 :2007	
@28 Days (Heat Ageing)	- 0.70 N/mm ²
@28 Days (Water Immersion)	- 0.80 N/mm ²
@28 Days (Water Immersion&Freez/Thaw)	- 0.60 N/mm ²
@28 Days (Standard Conditions)	– 1.00 N/mm ²
Shear Strength ANSI A 118.4	
@7 Days	– 0.75 N/mm ²
@28 Days	– 1.10 N/mm ²

APPLICABLE STANDARDS

BS 5950: 1980 as clause A Type 1 BS EN 12004:2007, ANSI 118.4 EN 1348, EN 1346:2007

WORK INSTRUCTIONS Substrate preparation

- The substrate must be sufficiently aged before tile installation.
- The substrate must be free of all traces of dust, oil, grease, wax and loose materials.
- Expansion joints must not be tiled over.
- Newly rendered surfaces must be allowed to cure for at least 7 days.
- : Steel-trowel finished concrete must be acid-etched or wire brushed prior to tiling.
- Painted surfaces must be scrapped to expose the
- original substrate.
- Highly absorbent substrates should be dampened before spreading TILEBOND.
- Defective and unsound substrates should be repaired prior to tile installation.
- Ensure that the backs of the tiles are not dusty.

Product preparation

- Add one 25kg bag TILEBOND to 5.5 6.0 litres of clean water, mixing thoroughly using a power mixer until a homogeneous (lump-free) mixture is achieved.
- Allow the mixture to stand for 10 minutes and remix prior to use.

TILEBOND GENERAL PURPOSE CEMENT-BASED TILE ADHESIVE



TILING AND GROUTING



Application

- Using a notched trowel, spread TILEBOND onto the substrate or onto the backface of the tiles. Both methods can be adopted when laying big tiles and tiles with deep grooves or ridges.
- To ensure good bonding, spread a thin coat of TILEBOND onto the surface using a straight edge trowel and then notch immediately with the correct thickness, using the suitable notched trowel depending on the type and size of the tiles.
- After applying TILEBOND, the tiles should be firmly pressed and knocked into position. Adjustment of tiles should be done within 15 minutes after installation.
- Do not spread more than 1m² of adhesive at one time and ensure that the adhesive is wet when the tiles are laid.
- Do not allow the adhesive to skin over prior to filling. If this occurs, it should be retrowelled to produce a fresh surface for receiving tiles.
 Ensure that there are no voids under the tiles by
- Ensure that there are no voids under the tiles by tapping tiles into position in order to ensure positive contact with the adhesive.

Grouting after tile installation

- Grouting should be carried out preferably at least 24 hours after the completion of tiling.
- For grout joints of up to 5 mm wide use SANITIZED COLOURED GROUT.

PRECAUTIONS

- Temperature range for use : +5°C to +45°C
- Apply only to clean, sound, resistant substrates, free of loose material.
- Clean tools and equipment with water before product dries.
- This product contains cement which may cause dermatitis. The use of protective gloves and goggles during handling is recommended. If skin irritation occurs seek medical attention promptly.

"The information provided in this document results from our knowledge of the product and our experience. On-site results may vary, in particular according to the product application methods adopted. Where application methods not covered by this document are used, customers must request additional information and /or carry out a representative test before using the products. The above- mentioned information in no way constitutes a warranty relative to the use of the products. Our general terms and conditions of sale shall prevail, in any event, on the information provided in this document. Prior to application, customers and users are requested to check that they have the latest version of this document"

Technical Documentation English-Version August 2006



 PAREX, PO Box 40508, Street N° 200, Zone 81, New Industrial Area, Doha, Qatar.
 Building appertise, togeth

 Tel: +974 44385111 Fax: +974 44604188 E-mail: infos.qatar@parex-group.com, www.parexgroupqatar.com

 manufactured by Parex Doha Qatar